

## Fitting your Vertical Drapes

**What you will need.**

1. Tape Measure and pencil
2. Appropriate Screws & Wall Anchors depending on what you are fixing too (not provided)
3. Cordless Drill / Screwdriver

### Instructions for Outside Mount

**Step 1.** Outside Mount (wall window or door frame)  
Start by marking the HEIGHT on wall. Unroll 1 fabric drape and measure on the floor, make the markings at the length of the fabric drape plus 50mm. (or the top point you measured from when ordering) This should allow approximately 25mm floor clearance. If you desire additional clearance, simply raise your marked length. After the height is determined, hold the L Bracket 100mm from the end of the window/door frame and select a solid fixing point. Mark with a pencil. Do this at the other end and then space the rest of the L Brackets evenly between the two ends.

If you are securing to plaster make sure you use appropriate wall anchors. (see your local hardware store for advise)



### Step 2

Screws are not provided because different wall material, ie plaster board, timber, aluminium will require different types of screws and wall anchors. Once you know what material you are mounting too ask your local hardware store for the appropriate fixing screws.

Using 2 screws per bracket secure them to the wall or architrave at the desired markings.



<p><b>Instructions for Inside Mount</b></p> <p>The most important point is that the screw point in the bracket has to be at least 70mm away from the most protruding part of the window (storm bars etc).</p> <p>This allows for the blades to turn without touching the window or storm bars etc.</p>	
--	--

**Step 3**

Once the all the brackets are secured, tilting the track (as shown) you need to insert the track into the front edge of the mounting clip then rotate back.


This will snap the track into place. Pay special attention to which side you wish to have your vertical blind draw. Put the cord on the left for a left draw and on the right for a right draw.



**Step 4**

Inserting the fabric drapes. As shown carefully clip each drape into the plastic hook. Work your way down the track until complete.





### Step 5

Mounting the child safe cord holder. It is law in most states of Australia to mount child safe cord holders.

Firstly screw the base of the holder to the wall. Use the nylon cord as your level indicator (as shown)

Try and find a solid fixing (stud etc) If not use an appropriate wall anchor.



### Step 6

Place the nylon cord and chain into the child safe cord holder.

Clip on the front of child safe cord holder.



**WARNING**

Young Children can become entangled and strangle in cord or head loops. Use safety devices to reduce access or eliminate loops. Young children can become entangled and strangle.



These instructions are also available in colour on our web site.

[www.imageblindsdirect.com.au/instructions.php](http://www.imageblindsdirect.com.au/instructions.php)